

SENSORTACK®

READY+



Application of SensorTack® Ready+:

- Remove rain/light sensor from windscreen.
- Remove old silicone pad completely.
- Clean sensor unit with SensorTack® Cleaning and contact spray and wipe away with a lint-free cloth.
- Remove pre-cut cover liner 1 of new SensorTack® Ready+ pad.
- Moisten sensor unit with Cleaning and contact spray.
- Use cover liner 2 to position sensor pad on sensor unit and remove cover liner.
- For bubble-free application, moisten SensorTack® Ready+ pad once more with Cleaning and contact spray (except Type 7 and Type 21 pad).
- Attach sensor to windscreen.
- Sensor can now be re-used.